

Option 1 – All small ends away from centre of trailer



Option 2 – A few small ends facing towards centre against stanchions to “level load”



Option 2 – Front View – a few small ends facing towards centre placed against stanchions to “level” load. Where space is limited personnel can reach in and measure logs on outside edges.



2-3 logs small ends facing inwards

Of the two options there is no preferred layout, the main points being:
That load does not have excessive slope.
Small ends can be accessed for scaling small ends.